

PURERITEK



Quick and simple installation and maintenance!

Item	Parameter
Working Voltage	AC100V-240V-50/60hz
Capacity	75G
Tank Capacity	3.2 G
Water Temperature	5-45°C
Removal Rate	>96%
Main Configuration	6 stages
Flush Mode	Auto Flushing
Inlet Water Pressure	0.15-0.35 MPa
Low Pressure Setting	0.05 MPa
High Pressure Setting	0.25 – 0.35 MPa

6 Stages to guarantee high water quality

Stage 1: PP sediment Filter. (10"x2.5")
5 Micron Sediment Filter cartridge removes sediment, dirt and rust from the feed water.


Stage 2: GAC granular carbon filters. (10"x2.5")
To absorb the unusual smell, chlorine and chlorine by-product.


Stage 3: CTO carbon block filter. (10"x2.5")
To remove chlorine, organic color, odour and floating particle.

Stage 4: TFC RO membrane TW -1812-75
To remove salts, bacteria, virus, chemical material, and heavy material.

Stage 5: Post Carbon filter
To improve the taste.


Stage 6: Mineral ball filter
In-Line Mineral Cartridge to raise pH, enhance the flavour, and enrich water with natural minerals.

 **Healthier Alternative** - Eliminates up to 99% of dissolved solids, chlorine, fluoride, microorganisms and heavy metals such as barium, cadmium, chromium, lead and mercury from water.

 **Auto Shut-Off** - Automatically shuts off water when cartridges are removed.

 **Easy Installations** - Quick connect fittings for easy installation.

 **Quality Control** - Valves are built into the heads to prevent back-flow for water quality assurance.

 **Higher Savings** - Long term savings with the reverse osmosis system eliminating the need to spend money on expensive bottled water.

